

Wildlife Materials International, Inc.

TRX-3, TRX-16, TRX-48S Receivers

TO CHANGE RECHARGEABLE BATTERY PACK:

After your warranty has expired, a battery pack can be changed at home. (When the receiver is under warranty, we change the battery at our facility, and then charge it, retune and recalibrate to insure quality performance.)

The battery is located in the **lower back** of receiver.

INSTRUCTIONS: PLEASE READ BEFORE ACTING

MOVE SLOWLY and GRADUALLY

- 1) Look at the receiver's face. Lift up the case's upper back, shorter section. Using a Phillips screwdriver, you'll need to remove 2 screws on each side of the upper back (a total of 4 screws to be removed).
- 2) You'll see the battery pack in the lower back compartment. Unplug the white plastic Molex connector of old battery pack. Remove old battery.
- 3) Insert new battery into lower back compartment. Plug in the Molex connector of new battery pack.
- 4) Fit the upper back shorter section of case to the bottom section. Make sure the top and bottom case sections are aligned, with corners smooth and screw holes matched. Tighten the two screws on each side of the case's top section. Make sure wires are not pinched.
- 5) **CHARGE BATTERY FOR 16 TO 24 HOURS.**
- 6) Test receiver. Hopefully it will not need to be retuned or recalibrated.

WARNING: Batteries installed incorrectly can cause wiring to burn up and/or batteries to explode. Be sure wires are not crimped when you put the unit back together.

Wildlife Materials International, Inc.

1202 Walnut Street Murphysboro, IL 62966 USA

Phone: 1-800-842-4537

FAX: 618-687-3539

FIVE-YEAR WARRANTY on ELECTRONICS